



EPXT-20 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004570	Main body	702	27020948	Pinion gear
105	21056616	Pinion bearing fixed bushing	705	27050218	Transmission gear
105	21050124	Pinion bearing fixed bushing	705	27050217	Transmission gear
112	21120204	Foot label decoration	708	27080189	Oscillating slider
200	22004654	Side plate	716	27160035	Oscillation slider plate
201	22011092	Main body decoration	718	27180801	Main shaft
201	22011093	Side plate decoration	719	27190025	Click gear
201	22011094	Main body decoration	722	27220009	Click gear washer
201	22011095	Side plate decoration	725	27250033	Transmission gear bushing
300	23005220	Rotor	800	28000437	Anti-reverse/anti-re lever
301	23012344	Bail arm	800	28000402	Anti-reverse/anti-re lever
304	23042880	Bail arm cover	801	28010024	Anti-re lever spring
305	23050232	Kick lever	0910618	0910618	One way assy.
307	23071902	Bail holder	0910221	0910221	Ball bearing
309	23090051	Bail arm support pin	0910051	0910051	Ball bearing
310	23100090	Compression spring	0910041	0910041	Ball bearing
313	23131876	Bail wire assy.	0910335	0910335	Ball bearing
315	23150086	Line roller	0920373	0920373	Washer
316	23160014	Line roller bushing	0920136	0920136	Washer
317	23170014	Line rollerwasher	0920590	0920590	Washer
318	23180005	Rotor nut	0920600	0920600	Washer
320	23200122	Rotor balance weight	0920235	0920235	Washer
400	240016040	Spool assy.	09301216	09301216	Screw
405	24050042	Drag washer retainer	0930541	0930541	Screw
407	24070009	Extension spring	09301525	09301525	Screw
412	24120038	Spool bushing	09301530	09301530	Screw
500	25006542	Handle assy.	0930431	0930431	Screw
504	25040007	Handle screw cap washer	0930438	0930438	Screw
513	25130921	Handle cap	09301327	09301327	Screw
600	26004363	Drag knob assy.	09301470	09301470	Screw
610	26100011	Drag washer	09301468	09301468	Screw
612	26120006	Key washer	09301454	09301454	Screw
612	26120054	Key washer	09301072	09301072	Screw
700	27000420	Drive gear			