



A-12NSIIa

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	11004956	Main body assy.	508	15080002	Push button spring	910	0910030	Ball bearing
100-1	11004955	Main body assy.	509	15090057	Handle knob	910	0910031	Ball bearing
102	11020092	Reel foot	510	15100112	Handle knob rivet	910	0910204	Bushing
102-1	11020084	Reel foot gasket	512	15120110	Handle knob cover assy.	910	0910524	Ball bearing
108	11080034	Hangers	513	15130031	Handle arm cap	910	0910567	Ball bearing
108-1	11080035	Hangers	515	15150002	Handle nut retainer screw	910	0910569	Ball bearing
114	11140073	Reel clamp assy.	516	15160055	Handle nut retainer	912	19120033	Cover plate
114-1	11140060	Reel clamp	516-1	15160057	Handle nut retainer assy.	920	0920025	Washer
115	11150025	Clamp screw	516-2	15160033	Handle nut retainer	920	0920079	Washer
116	11160016	Reel clamp nuts	517	15170034	Compression assy.	920	0920117	Washer
200	12002070	Handle side plate assy	600	16000175	Cast control cap assy.	920	0920283	Washer
201	12010085	Anti-re pawl	600-1	16000110	Cast drag knob	920	0920373	Washer
201-1	12010079	Holded plate	601	16010012	Compression spring	920	0920423	Washer
202	12020047	Ratchet	605	16050181	Lever drag assy.	920	0920427	Washer
203	12030008	Control pin	605-2	16050276	Lever knob	920	0920454	Washer
204	12040021	Compression spring	605-3	16050227	Lever drag assy.	920	0920558	Washer
204-2	12040027	Compression spring	607	16070086	Pinion guard	920	0920606	Washer
204-3	12040035	Compression spring	608	16080012	Drag washer retainer	920	09201007	Washer
205	12050040	Decortion plate	608-1	16080022	C type retainer	930	0930179	Screw
206	12060011	Stopper cap	609	16090023	Main shaft spring washer	930	0930211	Screw
209	32090003	Waved washer	610	16100074	Drag washer	930	0930241	Screw
216	12160016	Extension Spring	611	16110076	Eared washer	930	0930532	Screw
226	12260003	Ceramic ball	612	16120107	Key washer	930	0930872	Screw
241	12410002	Compression spring	700	17000450	H.S. main gear/pinion gear s	930	09301124	Screw
242	12420001	Compression spring	700-1	17000451	L.S. main gear/pinion gear s	930	09301167	Screw
243	12430004	Compression spring	701	17010314	Drive gear shaft	930	09301178	Screw
303	13030071	Click knob	717	17170015	Main shaft pin	930	09301219	Screw
304	13040017	Click pawl	718	17180376	Main shaft	930	09301222	Screw
305	13050013	Click pawl spring	726	17260012	Drive gear bushing	930	09301350	Screw
309	13090021	Clicker pin	900	19000005	E type retainer	930	09301425	Screw
400	14001108	Spool	900	19000006	E type retainer	930	09301522	Screw
401	14010032	Spool click gear	900	29000001	E type retainer	930	0930605	Screw
500	15000426	Handle arm assy.	901	19010006	C type retainer	940	0940013	O ring
500-1	15000388	Handle arm	901	19010010	C type retainer	PA1115	PA1115	Oil tank
501	15010025	Handle nut	901	19010022	C type retainer			
507	15070038	Push button assy.	901	19010026	C type retainer			
507-2	15070013	Clutch shift drive pin	902	19020003	Tool			