



CP-40 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004048	MAIN BODY	718	27180464	MAIN SHAFT
200	22003401	SIDE PLATE	719	27190017	CLICK GEAR
300	23004507	ROTOR	722	27220022	CLICK GEAR WASHER
301	23011408	BAIL ARM	722-1	27220023	CLICK GEAR WASHER
304	23042222	BAIL ARM COVER	725	27250020	TRANSMISSION GEAR BUSHING
305	23050128	KICK LEVER	800	28000377	ANTI-REVERSE/ANTI-RE LEVER
307	23071252	BAIL HOLDER	800-1	28000374	ANTI-REVERSE/ANTI-RE LEVER
309	23090030	BAIL ARM SUPPORT PIN	801	28010024	ANTI-RE LEVER SPRING
310	23100002	COMPRESSION SPRING	804	28040036	ANTI-RE PAWL
313	23131236	BAIL WIRE ASSY.	808	28080028	RATCHET
315	23150010	LINE ROTOR	809	28090018	SILENT SPRING
316	23160002	LINE ROLLER BUSHING	910-2	0910327	BALL BEARING
318	23180001	ROTOR NUT	910-3	0910361	BALL BEARING
400	240012498	SPOOL ASSY.	920-13	0920355	WASHER
413	24130003	WATERPROOF RETAINER	920-16	0920376	WASHER
416	24160005	SPOOL HOLD PLATE	920-2	0920151	WASHER
500	25004843	HANDLE ASSY.	920-3	0920075	WASHER
513	25130202	HANDLE CAP	930-1	0930998	SCREW
515	25150002	HANDLE SCREW CAP WASHER	930-2	0930470	SCREW
600	26003662	DRAG KNOB ASSY.	930-3	0930170	SCREW
610	26100055	DRAG WASHER	930-4	0930715	SCREW
611	26110019	EARED WASHER	930-5	0930640	SCREW
612	26120046	KEY WASHER	930-6	0930966	SCREW
612-2	26120047	KEY WASHER	930-7	0930214	SCREW
612-1	26120056	KEY WASHER	930-8	0930826	SCREW
700	27000264	DRIVE GEAR	930-10	09301054	SCREW
702	27020709	PINION GEAR	930-13	0930574	SCREW
705	27050076	TRANSMISSION GEAR	930-26	09301000	SCREW
708	27080060	OSCILLATING SLIDER	930-28	0930410	SCREW
716	27160005	OSCILLATION SLIDER PLATE	930-30	0930054	SCREW