



DRG-80 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21003977	Main body	700	27000332	Drive gear
105	0910332	Pinion bearing fixed plate	702	27020897	Pinion gear
105-1	0910396	Ball bearing plate	705	27050073	Transmission gear
108	21081353	Cap	708	27080069	Oscillating slider
200	22004308	Side plate	716	27160010	Oscillation slider plate
201	22010063	Main body decoration	718	27180614	Main shaft
201-1	22010064	Side plate decoration	719	27190005	Click gear
201-2	22010642	Side plate decoration	722	27220005	Click gear washer
201-3	22010643	Main body decoration	725	27250019	Transmission gear bushing
300	23004843	Rotor	800	28000256	Anti-reverse/anti-re lever
301	23011935	Bail arm	800-1	28000327	Anti-reverse/anti-re lever
304	23042514	Bail arm cover	801	28010039	Anti-re lever spring
305	23050136	Kick lever	0910494	0910494	Ball bearing
306	23060959	Bail holder cover	0910184	0910184	Ball bearing
307	23071538	Bail holder	0910141	0910141	Ball bearing
309	23090030	Bail arm slider	0920209	0920209	Washer
310	23100049	Compression spring	0920168	0920168	Washer
313	23131406	Bail wire assy.	0920169	0920169	Washer
315	23150011	Line roller	0920539	0920539	Washer
316	23160002	Line roller bushing	0930452	0930452	Screw
318	23180008	Rotor nut	0930575	0930575	Screw
400	240015026	Spool assy.	0930562	0930562	Screw
405	24050031	Drag washer retainer	0930945	0930945	Screw
407	24070006	Extension spring	0930044	0930044	Screw
412-1	24120018	Spool bushing	0930763	0930763	Screw
412-2	24120019	Spool bushing	0930471	0930471	Screw
500	25005908	Handle assy.	0930454	0930454	Screw
504	25040003	Handle screw cap washer	0930544	0930544	Screw
513	25130832	Handle cap	09301274	09301274	Screw
600	26002984	Drag knob assy.	0930643	0930643	Screw
610	26100053	Drag washer	0930972	0930972	Screw
611	26110021	Eared washer	09301085	09301085	Screw
612	26120063	Key washer	0930663	0930663	Screw
612-2	26120064	Key washer			