



DRGR-40 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21003973	Main body	611	26110015	Eared washer
105	21050027	Pinion bearing fixed plate	612	26120030	Key washer
105-1	21056578	Pinion bearing fixed bushing	612-1	26120054	Key washer
108	21081361	Cap	613	26130011	Clickretainer
200	22003988	Side plate	616	26160038	Drag rubber ring
201	22010059	Side plate decoration	700	27000322	Drive gear
201-1	22010060	Main body decoration	702	27020431	Pinion gear
201-2	22010638	Side plate decoration	705	27050105	Transmission gear
201-3	22010639	Main body decoration	708	27080086	Oscillating slider
202	22020019	Click pawl	709	27090003	"c" retainer
300	23004840	Rotor	718	27180523	Main shaft
301	23011934	Bail arm	725	27250020	Transmission gear bushing
304	23042509	Bail arm cover	800	28000242	Anti-reverse/anti-re lever
305	23050146	Kick lever	800-1	28000322	Anti-reverse/anti-re lever
306	23060956	Bail holder cover	801	28010024	Anti-re lever spring
307	23071536	Bail holder	0910633	0910633	Ball bearing
309	23090002	Bail arm slider	0910039	0910039	Ball bearing
310	23100005	Compression spring	0910049	0910049	Ball bearing
313	23131377	Bail wire assy.	0910091	0910091	Ball bearing
315	23150011	Line roller	0920540	0920540	Washer
316	23160002	Line roller bushing	0920376	0920376	Washer
318	23180005	Rotor nut	0920154	0920154	Washer
400	240014382	Spool assy.	0930060	0930060	Screw
407	24070009	Extension spring	0930575	0930575	Screw
500	25005904	Handle assy.	0930171	0930171	Screw
504	25040004	Handle screw cap washer	0930982	0930982	Screw
513	25130830	Handle cap	09301157	09301157	Screw
600	26001923	Drag knob	0930544	0930544	Screw
602	26020006	Drag spring	09301263	09301263	Screw
607	26070021	Drag knob holder	0930643	0930643	Screw
608	26080006	Drag washer	0930972	0930972	Screw
609	26090005	Click gear	0930840	0930840	Screw
610	26100042	Drag washer	0930639	0930639	Screw