



FPX-40 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21003687	Main body	612	26120054	Key washer
102	21020007	Bushing	612	26120004	Key washer
102-1	21020006	Bushing	700	27000322	Drive gear
105	21050027	Pinion bearing fixed plate	702	27020822	Pinion gear
105-1	21056578	Pinion bearing fixed bushing	705	27050105	Transmission gear
108	21081351	Cap	708	27080095	Oscillating slider
200	22003613	Side plate	716	27160007	Oscillation slider plate
201	22010636	Side plate decoration	718	27180704	Main shaft
201	22010637	Main body decoration	719	27190025	Click gear
201	22010029	Side plate decoration	722	27220009	Click gear washer
201	22010031	Main body decoration	725	27250020	Transmission gear bushing
300	23004674	Rotor	800	28000242	Anti-reverse/anti-re lever
301	23011622	Bail arm	800	28000322	Anti-reverse/anti-re lever
304	23042509	Bail arm cover	801	28010024	Anti-re lever spring
305	23050146	Kick lever	0910633	0910633	Ball bearing
306	23060956	Bail holder cover	0910049	0910049	Ball bearing
307	23071441	Bail holder	0920376	0920376	Washer
309	23090002	Bail arm slider	0920154	0920154	Washer
310	23100005	Compression spring	0920540	0920540	Washer
313	23131452	Bail wire assy.	0930043	0930043	Screw
315	23150010	Line roller	0930574	0930574	Screw
316	23160002	Line roller bushing	0930170	0930170	Screw
318	23180005	Rotor nut	09301253	09301253	Screw
400	240015708	Spool assy.	0930624	0930624	Screw
405	24050042	Drag washer retainer	0930054	0930054	Screw
407	24070009	Extension spring	0930470	0930470	Screw
500	25006297	Handle assy.	0930543	0930543	Screw
504	25040004	Handle screw cap washer	09301264	09301264	Screw
513	25130780	Handle cap	0930642	0930642	Screw
600	26002816	Drag knob assy.	0930966	0930966	Screw
610	26100011	Drag washer	0930836	0930836	Screw
611	26110004	Eared washer	0930638	0930638	Screw
612	26120003	Key washer			