



ISX-20R PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21009328	Main body	705-1	27050222	Transmission gear
105-1	21056616	Pinion bearing fixed bushing	708	27080175	Oscillating slider
105-2	21056619	Pinion bearing fixed bushing	716	27160030	Oscillation slider plate
112	21120187	Foot label decoration	718	27180783	Main shaft
200	22004537	Side plate	719	27190025	Click gear
201	22010787	Main body decoration	722	27220009	Click gear washer
300	23007398	Rotor	722-1	27220010	Click gear washer
301	23012106	Bail arm	725	27250032	Transmission gear bushing
304	23042805	Bail arm cover	800	28000437	Anti-reverse/anti-re lever
305	23050218	Kick lever	800-1	28000402	Anti-reverse/anti-re lever
307	23071810	Bail holder	801	28010024	Anti-re lever spring
309	23090051	Bail arm support pin	0910618	0910618	One way assy.
310	23100094	Compression spring	0910051	0910051	Ball bearing
313	23134340	Bail wire assy	0910041	0910041	Ball bearing
315	23150086	Line roller	0910221	0910221	Ball bearing
316	23160014	Line roller bushing	0910335	0910335	Ball bearing
317	23170024	Line roller washer	0920136	0920136	Washer
318	23180019	Rotor nut	0920600	0920600	Washer
320	23201168	Rotor balance weight	0920590	0920590	Washer
400	240015401	Spool assy	0920373	0920373	Washer
405	24050042	Drag washer retainer	0920237	0920237	Washer
407	24070009	Extension spring	0930438	0930438	Screw
412	24120038	Spool bushing	0930541	0930541	Screw
413	24130009	Waterproof retainer	09301453	09301453	Screw
500	25006224	Handle assy.	09301330	09301330	Screw
504	25040007	Handle screw cap washer	09301438	09301438	Screw
513	25130873	Handle cap	09301327	09301327	Screw
600	26003816	Drag knob assy.	0930044	0930044	Screw
610	26100011	Drag washer	09301072	09301072	Screw
612	26120006	Key washer	09301468	09301468	Screw
612-1	26120054	Key washer	09301454	09301454	Screw
700	27000420	Drive gear	0930429	0930429	Screw
702	27020841	Pinion gear	09301467	09301467	Screw
705	27050201	Transmission gear			