



MK-50II

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	11001701	Main body assy.	508	15080002	Clutch retainer spring	910	0910441	Ball bearing
100-1	11001660	Main body	509	15090076	Handle knob	910	0910443	Ball bearing
102	11020051	Reel foot	510	15100111	Handle pin	910	0910448	Ball bearing
102-1	11020058	Reel foot gasket	512	15120093	Handle knob cover	910	0910474	Ball bearing
108	11080025	Hangers	513	15130030	Handle cover	913	19130008	Waved spring
108-1	11080028	Hangers	515	15150002	Handle nut retainer screw	920	0920004	Washer
114	11140074	Reel clamp assy.	516	15160034	Handle nut retainer	920	0920040	Washer
114-1	11140075	Reel clamp	516-1	15160038	Handle nut retainer assy.	920	0920154	Washer
115	11150027	Reel clamp screws	516-2	15160033	Handle nut retainer	920	0920412	Washer
116	11160015	Reel clamp nuts	517	15170022	Clutch shift pin assy.	920	0920440	Washer
117	11170027	Hexagon nut	600	16000104	Cast control cap assy.	920	0920447	Washer
117-1	11170026	Hexagon nut	602	16020040	Adjustable block	920	0920455	Washer
200	12002104	Handle side plate assy.	605	16050119	Lever drag assy.	920	0920473	Washer
201	12010051	Anti-re pawl assy.	605-1	16050096	Lever side chip	920	0920479	Washer
201-1	12010052	Anti-re pawl assy.	605-3	16050226	Lever drag assy.	920	0920486	Washer
202	12020023	Ratchet	607	16070079	Pinion guard	920	0920496	Washer
203	12030004	Control pin	608	16080012	C type retainer	920	0920507	Washer
204	12040002	Compression spring	609	16090021	Main shaft spring washer	920	09201008	Washer
204-1	12040025	Compression spring	609-1	16090019	Main shaft spring washer	930	0930075	Screw
204-2	12040027	Compression spring	611	16110051	Eared washer	930	0930084	Screw
204-3	12040035	Compression spring	612	16120079	Key washer	930	0930086	Screw
204-4	12040023	Compression spring	612-1	16120080	Key washer	930	0930211	Screw
205	12050047	Decoration plate	620	16200001	Drag cam bushing	930	0930532	Screw
206	12060011	Lever drag stopper cap	622	16220022	Top cover for star drag	930	0930605	Screw
207	12070087	Holder plate	623	16230012	Under cover for star drag	930	09301117	Screw
211	12110014	Anti-re pawl pin	700	17000460	H.S. main gear/pinion gear set	930	09301124	Screw
215	12150028	Holded plate bushing	700	17000038	Low speed drive gear	930	09301152	Screw
217	12170037	Anti-re pawl spring	701	17010268	Drive gear shaft	930	09301193	Screw
226	12260003	Ceramic ball	702	17020363	Low speed pinion gear	930	09301194	Screw
242	12420007	Compression spring	717	17170013	Main shaft pin	930	09301195	Screw
300	13000201	Vice side plate	718	17180336	Main shaft	930	09301197	Screw
303	13030076	Click knob assy.	723	17230025	Silent spring bushing	930	09301201	Screw
304	13040022	Click pawl	723-1	17230028	R/ side silent spring	930	09301220	Screw
400	14000854	Spool assy.	723-2	17230029	L/ side silent spring	930	09301413	Screw
401	14010037	Spool click gear	900	19000004	E type retainer	930	09301416	Screw
405	14050038	Spool cover	900	29000001	E type retainer	940	0940027	O ring
500	15000069	Handle arm assy.	901	19010015	C type retainer	PA1115	PA1115	Oil tank
500-1	15000395	Handle arm	901	19010022	C type retainer			
501	15010010	Handle nut	901	19010023	C type retainer			
507	15070039	Push button assy.	902	19020002	Tool			
507-2	15070027	Clutch shift drive pin	910	0910410	Thrust bearing assy.			