



PTN-40 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004580	Main body	612	26120007	Key washer
105	21050027	Pinion bearing fixed plate	700	27000322	Drive gear
105	21056578	Pinion bearing fixed bushing	702	27020822	Pinion gear
108	21081573	Cap	705	27050105	Transmission gear
200	22004662	Side plate	708	27080095	Oscillating slider
201	22011125	Side plate decoration	716	27160007	Oscillation slider plate
201	22011126	Main body decoration	718	27180704	Main shaft
201	22010029	Side plate decoration	719	27190025	Click gear
201	22010031	Main body decoration	722	27220009	Click gear washer
300	23005232	Rotor	725	27250020	Transmission gear bushing
301	23011535	Bail arm	800	28000242	Anti-reverse/anti-re lever
304	23049839	Bail arm cover	800	28000322	Anti-reverse/anti-re lever
305	23050146	Kick lever	801	28010024	Anti-re lever spring
306	23067142	Bail holder cover	0910633	0910633	One way ball bearing
307	23071407	Bail holder	0910039	0910039	Ball bearing
309	23090002	Bail arm slider	0910049	0910049	Ball bearing
310	23100005	Compression spring	0910091	0910091	Ball bearing
313	23131481	Bail wire assy.	0920540	0920540	Washer
315	23150010	Line roller	0920376	0920376	Washer
316	23160002	Line roller bushing	0920154	0920154	Washer
318	23180005	Rotor nut	0930044	0930044	Screw
400	240016092	Spool assy.	0930575	0930575	Screw
405	24050042	Drag washer retainer	0930171	0930171	Screw
407	24070009	Extension spring	09301252	09301252	Screw
412	24120022	Spool bushing	0930209	0930209	Screw
500	25006535	Handle assy.	0930055	0930055	Screw
504	25040004	Handle screw cap washer	0930471	0930471	Screw
513	25130909	Handle cap	0930544	0930544	Screw
600	26004389	Drag knob assy.	09301265	09301265	Screw
610	26100011	Drag washer	0930643	0930643	Screw
611	26110005	Eared washer	0930964	0930964	Screw
612	26120006	Key washer	0930838	0930838	Screw
612	26120054	Key washer	0930639	0930639	Screw