



SLX-10CS PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	11001980	Main body assv	700	17000397	Drive gear
107	11070024	Line guard	701	17010307	Drive gear shaft
114	11140037	Clamp	702	17020503	Pinion gear
115	11150003	Wing screw	717	17170004	Main shaft pin
116	11160003	Reel clamp nuts	718	17180364	Main shaft
117	11170002	Retainer nut	723	17230006	Silent spring
200	12002096	Handle side plate	913	19130002	Spring washer
201	12010033	Anti-re pawl	19000001	19000001	E retainer
203	12030004	Control pin	29010001	29010001	Click pawl washer
204	12040002	Compression spring	19010006	19010006	C retainer
204	12040018	Compression spring	0910598	0910598	Thrust bearing assv
206	12060010	Lever drag stopper cap	0910599	0910599	Thrust bearing assv
207	12070071	Holed plate	0910432	0910432	Ball bearing
208	12080108	Side plate cover	0910145	0910145	Ball bearing
215	12150016	Hold plate bushing	0910344	0910344	Ball bearing
215	12150019	Hold plate bushing	0910036	0910036	Ball bearing
215	12150020	Hold plate bushing	0910590	0910590	Ball bearing
216	12160011	Anti-re pawl spring	0920481	0920481	Washer
217	12170012	Anti-re pawl spring	0920490	0920490	Washer
217	12170016	Anti-re pawl spring	0920126	0920126	Washer
225	12250001	Bushing	0920154	0920154	Washer
226	12260004	Control pin	0920492	0920492	Washer
300	13000619	Vice side plate	0920218	0920218	Washer
303	13030090	Click button	0920310	0920310	Washer
304	13040018	Click pawl	0920319	0920319	Washer
305	13050009	Click pawl spring	0920373	0920373	Washer
311	13110101	Side plate covers	0920106	0920106	Washer
400	14001048	Spool	0920207	0920207	Washer
401	14010042	Spool click gear	0920009	0920009	Washer
405	14050024	Spool cover	0920418	0920418	Washer
406	14060006	Bushing	0920510	0920510	Washer
500	15000460	Handle assv.	0920304	0920304	Washer
501	15010019	Handle nut	0930219	0930219	Screw
507	15070032	Push button	09301128	09301128	Screw
513	15130023	Handle cover	0930885	0930885	Screw
516	15160030	Handle nut retainer	0930196	0930196	Screw
600	16000086	Cast control cap	0930628	0930628	Screw
601	16010004	Compression spring	0930893	0930893	Screw
602	16020050	Adjust block	0930666	0930666	Screw
605	16050209	Lever drag assv.	0930044	0930044	Screw
607	16070047	Pinion guard	0930651	0930651	Screw
608	16080004	Drag washer retainer	0930211	0930211	Screw
609	16090013	Spring washer	09301095	09301095	Screw
611	16110048	Drag washer	0930615	0930615	Screw
612	16120059	Key washer	0930129	0930129	Screw
612	16120103	Key washer	0940056	0940056	O ring
613	16130005	Compression spring			