



SLX-15L PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	11001986	Main body assy.	704	17040018	Line guide support bar
101	11010036	Body load	705	17050013	Transmission gear
105	11050006	Worm shaft bushing	707	17070004	Transmission gear
105-1	11050007	Worm shaft bushing	710	17100030	Line guide assy.
114	11140037	Clamp	712	17120056	Worm shaft
115	11150003	Wing screw	713	17130002	Line guide pawl can
116	11160003	Reel clamp nuts	715	17150009	Line guide pawl
117	11170002	Retainer nut	717	17170004	Main shaft pin
200	12002096	Handle side plate	718	17180366	Main shaft
201	12010033	Anti-re pawl	723	17230006	Silent spring
203	12030004	Control pin	913	19130002	Spring washer
204	12040002	Compression spring	19000001	19000001	E retainer
204-1	12040018	Compression spring	29000001	29000001	E retainer
206	12060010	Lever drag stopper can	29010001	29010001	Click pawl washer
207	12070071	Holed plate	19010006	19010006	C retainer
208	12080108	Side plate cover	0910600	0910600	Thrust bearing assy
215	12150016	Hold plate bushing	0910599	0910599	Thrust bearing assy
215-1	12150019	Hold plate bushing	0910432	0910432	Ball bearing
215-2	12150020	Hold plate bushing	0910145	0910145	Ball bearing
216	12160011	Anti-re pawl spring	0910344	0910344	Ball bearing
217	12170012	Anti-re pawl spring	0910036	0910036	Ball bearing
217-1	12170016	Anti-re pawl spring	0910590	0910590	Ball bearing
225	12250001	Bushing	0920510	0920510	Washer
226	12260004	Control pin	0920126	0920126	Washer
300	13000619	Vice side plate	0920154	0920154	Washer
303	13030090	Click button	0920481	0920481	Washer
304	13040018	Click pawl	0920490	0920490	Washer
305	13050009	Click pawl spring	0920492	0920492	Washer
311	13110101	Side plate covers	0920218	0920218	Washer
400	14001074	Spool	0920373	0920373	Washer
401	14010042	Spool click gear	0920121	0920121	Washer
405	14050024	Spool cover	0920106	0920106	Washer
406	14060006	Bushing	0920207	0920207	Washer
500	15000460	Handle assy.	0920009	0920009	Washer
501	15010019	Handle nut	0920418	0920418	Washer
507	15070032	Push button	0920066	0920066	Washer
509	35090001	E retainer	0920120	0920120	Washer
513	15130023	Handle cover	0920282	0920282	Washer
516	15160030	Handle nut retainer	0920304	0920304	Washer
600	16000086	Cast control can	09301128	09301128	Screw
601	16010004	Compression spring	0930885	0930885	Screw
602	16020050	Adjust block	0930196	0930196	Screw
605	16050209	Lever drag assy.	0930628	0930628	Screw
607	16070047	Pinion guard	0930893	0930893	Screw
608	16080004	Drag washer retainer	0930666	0930666	Screw
609	16090013	Spring washer	0930219	0930219	Screw
611	16110048	Drag washer	0930044	0930044	Screw
612	16120059	Key washer	0930651	0930651	Screw
612-1	16120103	Key washer	0930211	0930211	Screw
613	16130005	Compression spring	09301095	09301095	Screw
700	17000395	Drive gear	0930615	0930615	Screw
701	17010307	Drive gear shaft	0930129	0930129	Screw
702	17020501	Pinion gear	0940056	0940056	O ring
703	17030005	Worm shaft guard			