



SLX-20 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	11001976	Main body assy	612	16120064	Key washer
101	11010033	Body load	612-1	16120102	Key washer
102	11020103	Body foot	613	16130007	Compression spring
103	11030003	Screw	700	17000403	Drive gear
104	11040001	Body foot nut	701	17010309	Drive gear shaft
107-1	11070041	Line guard	702	17020505	Pinion gear
108	11080018	Hanger	717	17170004	Main shaft pin
108-1	11080030	The protection cover of reels lugs	718	17180368	Main shaft
114	11140005	Clamp	723	17230009	Silent spring
115	11150006	Wung screw	913	19130002	Spring washer
116	11160003	Reel clamp nuts	19000004	19000004	E retainer
117	11170002	Retainer nut	19010006	19010006	C retainer
200	12002095	Handle side plate	0910592	0910592	Ball bearing
201	12010027	Anti-re pawl	0910591	0910591	Ball bearing
203	12030004	Control pin	0910599	0910599	Thrust bearing assy
204	12040002	Compression spring	0910586	0910586	Thrust bearing assy
205	12050033	Decoration plate	0910179	0910179	Ball bearing
206	12060016	Stopper cap	0910103	0910103	Ball bearing
207	12070076	Holded plate	0920490	0920490	Washer
208	12080106	Side plate cover	0920481	0920481	Washer
215	12150022	Hold plate bushing	0920503	0920503	Washer
215-1	12150023	Hold plate bushing	0920319	0920319	Washer
217	12170014	Anti-re pawl spring	0920218	0920218	Washer
217-1	12170018	Anti-re pawl spring	0920209	0920209	Washer
300	13000618	Vice side plate	0920506	0920506	Washer
303	13030012	Click button	0920510	0920510	Washer
304	13040019	Click pawl	09201000	09201000	Washer
305	13050014	Click pawl spring	0920207	0920207	Washer
311	13110098	Side plate covers	0920263	0920263	Washer
400	14001072	Spool	0920426	0920426	Washer
401	14010036	Click gear	0920004	0920004	Washer
405	14050031	Spool cover	0920152	0920152	Washer
406	14060006	Bushing	0930048	0930048	Screw
500	15000457	Handle assy.	09301052	09301052	Screw
501	15010013	Handle nut	0930129	0930129	Screw
507	15070032	Push button	09301130	09301130	Screw
513	15130025	Handle cover	0930651	0930651	Screw
516	15160030	Handle nut retainer	0930668	0930668	Screw
600	16000101	Cast control cap	09301256	09301256	Screw
601	16010004	Compression spring	0930044	0930044	Screw
602	16020049	Adjust block	0930614	0930614	Screw
605	16050207	Lever drag assy.	0930646	0930646	Screw
607	16070093	Pinion guard	0930196	0930196	Screw
608	16080004	Drag washer retainer	0930211	0930211	Screw
609	16090012	Spring washer	09301115	09301115	Screw
611	16110050	Drag washer	0940056	0940056	O ring