



Key No.	Part No.	Part Name	Part No.	Part Name
1	5K1388050	Palm Side Cover Assembly	5K1558010	Bearing
2	5K1348011	Lock Pin	5K0270010	Washer
3	6K9744010	Coil Spring	6K1811010	Washer
4	5K1023010	Magnet Holder Assembly	6K1812024	Tension Nut
5	5K0470010	Tap Screw	6K3113060	Screw
6	5K0270010	Washer	6K2569010	Bearing
7	6K7589010	Bearing	632014020	Retainer
8	6K4683010	Ring	5K1349010	Bearing Plate
9	5K1344072	Spool Assembly	635359020	Screw
10	6K3113110	Screw	5K0936040	Gear Metal
11	6K3113060	Screw	6K2581010	Gear
12	6K3956040	Screw	6K8936021	Ratchet
13	6B3398010	Retainer	5K0271010	Washer
14	6K4568012	Bush	5K1313020	Drive Gear
15	6K9311040	Level Wind Assembly	5K0399010	Washer-L
16	6K2565012	Level Wind Pin	5K0400010	Washer-D
17	6K1488010	Washer	6K8592011	Sleeve
18	6K7044030	Level Wind Nut	6K1773020	Washer
19	6K4564033	Pipe	6K5822010	Ball Bearing
20	5K0956030	Worm Shaft	6K1773010	Washer
21	6E0965030	Washer	6K2592014	Leaf Spring Assembly
22	6K4693010	Worm Pinion	5K0272010	Spring Washer
23	6B3398010	Retainer	6K1936010	Washer
24	5K1367010	Hood	5K1338050	Star Drag Assembly
25	6K9304011	Pillar	6K1614040	Leaf Spring
26	5K1389032	Frame Assembly	5K1353050	Handle Assembly
27	5K1383030	Thumb Bar Assembly	6K1783101	Handle Nut
28	5K1373010	Kick Lever Spring	6K3110040	Handle Nut Cap
29	5K1382010	Kick Lever	635118050	Screw

30	5K1384010	Clutch Cam Spring	5K1324060	Control Dial
31	5K1372010	Clutch Cam	6K9747011	Leaf Spring
32	6K7876010	Screw	6K1802010	O-Ring
33	6K7876010	Screw	5K1327010	Slide Cam-B
34	5K1334010	Clutch	5K1005011	Coil Spring
35	6K9425010	Coil Spring	5K0962011	Slide Cam-A
36	5K1538020	Pinion	5K1263010	Spool Cover
37	5K1385060	Gear Side Cover Assembly	6E0965030	Washer
38	6K1765010	O-Ring		