



X-SPOT PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21003457	Main body	712	27120008	Worm shaft
102	21020001	Bushing	714	27140007	Worm shaft bushing
103	21030005	Kick lever	715	27150001	Line guide pawl
105	21050042	Pinion bearing fixed plate	716	27160017	Oscillation slider plate
105	0910396	Ball bearing plate	716	27160002	Oscillation slider plate
108	21081070	Cap	718	27180782	Main shaft
200	22003399	Side plate	719	27190033	Click gear
300	23004502	Rotor	721	27210013	Main shaft bushing
301	23011627	Bail arm	722	27220028	Click gear washer
304	23043366	Bail arm cover	734	27340001	Line guide pwal bushing
306	23067144	Bail holder cover	735	27350001	Washer
307	23071293	Bail holder	800	28000442	Anti-reverse/anti-re lever
309	23090030	Bail arm slider	801	28010014	Anti-re lever spring
310	23100049	Compression spring	0910416	0910416	Ball bearing
313	23134335	Bail wire assy.	0910184	0910184	Ball bearing
315	23150034	Line roller	0910139	0910139	Ball bearing
317	23170008	Line roller washer	0920209	0920209	Washer
318	23180008	Rotor nut	0920377	0920377	Washer
327	23270009	Defend winding retainer	0920252	0920252	Washer
400	240015330	Spool assy.	0920360	0920360	Washer
405	24050048	Darg washer retainer	0920409	0920409	Washer
407	24070006	Extension spring	0930044	0930044	Screw
412	24120055	Spool bushing	0930663	0930663	Screw
412	24120018	Spool bushing	0930477	0930477	Screw
412	24120019	Spool bushing	0930547	0930547	Screw
500	25006085	Handle assy.	0930438	0930438	Screw
504	25040008	Handle screw cap washer	0930639	0930639	Screw
513	25130538	Handle cap	0930448	0930448	Screw
600	26003824	Drag knob	0930058	0930058	Screw
610	26100053	Drag washer	0930301	0930301	Screw
610	26100096	Drag washer	0930201	0930201	Screw
612	26120064	Key washer	0930538	0930538	Screw
700	27000179	Drive gear	09301272	09301272	Screw
702	27020231	Pinion gear	0930643	0930643	Screw
703	27030023	Pinion gear bushing	09301351	09301351	Screw
706	27060014	Worm shaft gear	0930810	0930810	Screw
708	27080049	Oscillating slider			